



## Volvo Cars Accessories

**XC90**  
**(16-) 2017**  
L.H.D

United States



### Mat, passenger compartment floor, moulded plastic

Op. No.: 85532

Floor mats, including a tunnel mat, for the passenger compartment floor. The mats are made of soft and flexible plastic, which have a rubber feel. They have raised edges all around, which give protection against wet and dirt on the car's interior.

The material is rugged and designed in a pattern with soft edges and radii. The driver's mat has a comfortable textile foot plate that protects the shoes from wear.

Both the colour and shape of the mats are matched to make them seem integrated with the car's interior.

The mats are easy to install and seal tight against the floor. They are fixed with integrated clips through leak-protected installation holes. The mats are easily removed and can be rinsed off with water.

#### Charcoal 5 and 7 seats (kit of five mats - four floor mats and a tunnel mat)

Part. No.	Description
39828620	R100, RD00, RA00, RB00, RC00, RB01, RB0R, RC0R, RA20, RB20, RC20, RB21, UA00, UB00, UC00, UB01 , LHD, Image 1

#### Blond 5 and 7 seats (kit of five mats - four floor mats and a tunnel mat)

Part. No.	Description
39830541	WA00, WB00, WC00, WB01, QA00, QB00, QC00, QB01 , LHD, Image 2

#### Charcoal 7 seats, third row (one mat)

Part. No.	Description
39832193	R100, RD00, RA00, RB00, RC00, RB01, RB0R, RC0R, RA20, RB20, RC20, RB21, UA00, UB00, UC00, UB01 , Image 1

#### Blond 7 seats, third row (one mat)

Part. No.	Description
-----------	-------------

39833196

WA00, WB00, WC00, WB01, QA00, QB00, QC00, QB01 , Image 2

### Facts and advantages

- Waterproof.
- Colour coded and harmonised with the rest of the interior.
- Easy to clean.
- Easy to install and remove from the car.
- Kept in place with clips.

### Technical data

Material: TPE (Thermoplastic elastomer)  
3.6 kg (5 seats)  
Accessory weight: 5.1 kg (7 seats)  
1.5 kg (7 seats, third row)

#### Colour code table - Upholstery/Interior

Colour code	Description
R100, RD00, RA00, RB00, RC00, RB01, RB0R, RC0R	Charcoal
RA20, RB20, RC20, RB21	Charcoal / Amber
UA00, UB00, UC00, UB01, WA00, WB00, WC00, WB01	Blond / Charcoal
QA00, QB00, QC00, QB01	Blond / Espresso

#### Note!

The tunnel mat is not suitable for Twin Engine.

Last updated: 5/3/2016