


03 Instruments and controls



03 Instruments and controls



03

	Function	See
0	Controls for menus and messages, turn signals, high/low beams, trip computer	(p. 74), (p. 93), (p. 87), (p. 113)
0	Paddles for manually shifting gears*	(p. 259)
8	Cruise control	(p. 176)
4	Horn, airbag	(p. 85), (p. 33)
6	Main instrument panel	(p. 66)
6	Infotainment system/ Bluetooth hands-free controls	Sensus Info- tainment supplement
7	START/STOP ENGINE button	(p. 76)
8	Ignition slot	(p. 76)
0	Display for infotain- ment system func- tions and menus	(p. 111), Sensus Info- tainment supplement
10	Door handle	-

	Function	See
1	In-door control pan- els (power windows, mirrors, central lock- ing button)	(p. 99), (p. 100), (p. 160)
Ð	Hazard warning flashers	(p. 93)
13	Controls for the info- tainment system and menus	(p. 74), (p. 126), Sensus Info- tainment supplement
12	Climate system con- trols	(p. 126)
Ф	Gear selector	(p. 257)
16	Controls for active chassis (Four-C)*	(p. 169)
Ð	Wipers and washers	(p. 96), (p. 97)
13	Steering wheel adjustment	(p. 85)
❶	Hood opening control	(p. 331)
2	Parking brake	(p. 274)

	Function	See
2	Power seat* adjust- ment controls	(p. 79)
22	Lighting panel, but- tons for opening fuel filler door and unlocking the tailgate	(p. 87), (p. 283), (p. 162)

Related information

- Information displays ambient temperature sensor (p. 75)
- Information displays trip odometer and clock (p. 76)